

Omdurman Islamic University

Faculty of Engineering

Electrical & Electronic Engineering
(4th year)

Signal Processing and Systems

Lecturer
FAWAZ FATHI

Module 3

Continuous-Time Linear
Time-Invariant (LTI)
Systems

Course Description (Part 1)

- Module 1: Introduction to signals and systems.
- Module 2: Continuous-Time (CT) Signals and Systems
- Module 3: Continuous-Time Linear Time-Invariant (LTI) Systems
- Module 4: Continuous-Time Fourier Series (CTFS)
- Module 5: Continuous-Time Fourier Transform (CTFT)
- Module 6: Laplace Transform (LT)

Course Description (Part2)

- Module 1: Introduction to Digital signal Processing.
- Module 2: Analogue to Digital conversion, Sampling, Quantization
- Module 3-1: Digital signal and systems .
- Module 3-2: LTI systems described by difference equations.
- Module 4-1: Discrete Time Fourier Transform.
- Module 4-2: Fast Fourier Transforms (FFT).

Course Description (Part2)

- Module 5: Z Transform
- Module 6: Basic Filtering Types
- Module 7: FIR Filters design, implementation.
- Module 8: IIR Filters design, implementation.

Part 1

Continuous-Time
Linear Time-
Invariant (LTI)
Systems

Why Linear Time-Invariant (LTI) Systems?

- In engineering, linear-time invariant (LTI) systems play a very important role.
- Very powerful mathematical tools have been developed for analyzing LTI systems.
- LTI systems are much easier to analyze than systems that are not LTI.
- In practice, systems that are not LTI can be well approximated using LTI models.
- So, even when dealing with systems that are not LTI, LTI systems still play an important role.

Section 3.1

Convolution

CT Convolution

- The (CT) **convolution** of the functions x and h , denoted $x * h$, is defined as the function

$$x * h(t) = \int_{-\infty}^{\infty} x(\tau)h(t - \tau)d\tau.$$

- The convolution result $x * h$ evaluated at the point t is simply a weighted average of the function x , where the weighting is given by h time reversed and shifted by t .
- Herein, the asterisk symbol (i.e., “*”) will always be used to denote convolution, not multiplication.
- As we shall see, convolution is used extensively in systems theory.
- In particular, convolution has a special significance in the context of LTI systems.

Practical Convolution Computation

- To compute the convolution

$$x * h(t) = \int_{-\infty}^{\infty} x(\tau)h(t - \tau)d\tau.$$

we proceed as follows:

- 1 Plot $x(\tau)$ and $h(t - \tau)$ as a function of τ .
- 2 Initially, consider an arbitrarily large negative value for t . This will result in $h(t - \tau)$ being shifted very far to the left on the time axis.
- 3 Write the mathematical expression for $x * h(t)$.
- 4 Increase t gradually until the expression for $x * h(t)$ changes form. Record the interval over which the expression for $x * h(t)$ was valid.
- 5 Repeat steps [3](#) and [4](#) until t is an arbitrarily large positive value. This corresponds to $h(t - \tau)$ being shifted very far to the right on the time axis.
- 6 The results for the various intervals can be combined in order to obtain an expression for $x * h(t)$ for all t .

Properties of Convolution

- The convolution operation is *commutative*. That is, for any two functions x and h ,

$$x * h = h * x.$$

- The convolution operation is *associative*. That is, for any signals x , h_1 , and h_2 ,

$$(x * h_1) * h_2 = x * (h_1 * h_2).$$

- The convolution operation is *distributive* with respect to addition. That is, for any signals x , h_1 , and h_2 ,

$$x * (h_1 + h_2) = x * h_1 + x * h_2.$$

Representation of Signals Using Impulses

- For any function x ,

$$x(t) = \int_{-\infty}^{\infty} x(\tau) \delta(t - \tau) d\tau = x * \delta(t).$$

- Thus, any function x can be written in terms of an expression involving δ .
- Moreover, δ is the *convolutional identity*. That is, for any function x ,

$$x * \delta = x.$$

Periodic Convolution

- The convolution of two periodic functions is usually not well defined.
- This motivates an alternative notion of convolution for periodic signals known as periodic convolution.
- The **periodic convolution** of the T -periodic functions x and h , denoted $x \circledast h$, is defined as

$$x \circledast h(t) = \int_T x(\tau) h(t - \tau) d\tau,$$

where \int_T denotes integration over an interval of length T .

- The periodic convolution and (linear) convolution of the T -periodic functions x and h are related as follows:

$$x \circledast h(t) = x_0 * h(t) \quad \text{where} \quad x(t) = \sum_{k=-\infty}^{\infty} x_0(t - kT)$$

(i.e., $x_0(t)$ equals $x(t)$ over a single period of x and is zero elsewhere).

Section 3.2

Convolution and LTI Systems

Impulse Response

- The response h of a system H to the input δ is called the **impulse response** of the system (i.e., $h = H\{\delta\}$).
- For any LTI system with input x , output y , and impulse response h , the following relationship holds:

$$y = x * h.$$

- In other words, a LTI system simply *computes a convolution*.
- Furthermore, a LTI system is *completely characterized* by its impulse response.
- That is, if the impulse response of a LTI system is known, we can determine the response of the system to any input.
- Since the impulse response of a LTI system is an extremely useful quantity, we often want to determine this quantity in a practical setting.
- Unfortunately, in practice, the impulse response of a system cannot be determined directly from the definition of the impulse response.

Step Response


- The response s of a system H to the input u is called the **step response** of the system (i.e., $s = H\{u\}$).
- The impulse response h and step response s of a system are related as

$$h(t) = \frac{ds(t)}{dt}.$$

- Therefore, the impulse response of a system can be determined from its step response by differentiation.
- The step response provides a practical means for determining the impulse response of a system.


Block Diagram Representation of LTI Systems

- Often, it is convenient to represent a (CT) LTI system in block diagram form.
- Since such systems are completely characterized by their impulse response, we often label a system with its impulse response.
- That is, we represent a system with input x , output y , and impulse response h , as shown below.




Interconnection of LTI Systems

- The *series* interconnection of the LTI systems with impulse responses h_1 and h_2 is the LTI system with impulse response $h = h_1 * h_2$. That is, we have the equivalences shown below.



- The *parallel* interconnection of the LTI systems with impulse responses h_1 and h_2 is a LTI system with the impulse response $h = h_1 + h_2$. That is, we have the equivalence shown below.



Section 3.3

Properties of LTI Systems

Memory

- A LTI system with impulse response h is memoryless if and only if

$$h(t) = 0 \quad \text{for all } t \neq 0.$$

- That is, a LTI system is memoryless if and only if its impulse response h is of the form

$$h(t) = K\delta(t),$$

where K is a complex constant.

- Consequently, every memoryless LTI system with input x and output y is characterized by an equation of the form

$$y = x * (K\delta) = Kx$$

(i.e., the system is an ideal amplifier).

- For a LTI system, the memoryless constraint is extremely restrictive (as every memoryless LTI system is an ideal amplifier).

- A LTI system with impulse response h is causal if and only if

$$h(t) = 0 \quad \text{for all } t < 0$$

(i.e., h is a causal signal).

- It is due to the above relationship that we call a signal x , satisfying

$$x(t) = 0 \quad \text{for all } t < 0,$$

a causal signal.

Invertibility

- The inverse of a LTI system, if such a system exists, is a LTI system.
- Let h and h_{inv} denote the impulse responses of a LTI system and its (LTI) inverse, respectively. Then,

$$h * h_{\text{inv}} = \delta.$$

- Consequently, a LTI system with impulse response h is invertible if and only if there exists a function h_{inv} such that

$$h * h_{\text{inv}} = \delta.$$

- Except in simple cases, the above condition is often quite difficult to test.

- A LTI system with impulse response h is BIBO stable if and only if

$$\int_{-\infty}^{\infty} |h(t)| dt < \infty$$

(i.e., h is *absolutely integrable*).

Eigenfunctions of Systems

- An input x to a system H is said to be an **eigenfunction** of the system H with the **eigenvalue** λ if the corresponding output y is of the form

$$y = \lambda x,$$

where λ is a complex constant.

- In other words, the system H acts as an ideal amplifier for each of its eigenfunctions x , where the amplifier gain is given by the corresponding eigenvalue λ .
- Different systems have different eigenfunctions.
- Of particular interest are the eigenfunctions of LTI systems.

Eigenfunctions of LTI Systems

- As it turns out, every complex exponential is an eigenfunction of all LTI systems.
- For a LTI system H with impulse response h ,

$$H\{e^{st}\} = H(s)e^{st},$$

where s is a complex constant and

$$H(s) = \int_{-\infty}^{\infty} h(t)e^{-st} dt.$$

- That is, e^{st} is an eigenfunction of a LTI system and $H(s)$ is the corresponding eigenvalue.
- We refer to H as the **system function** (or **transfer function**) of the system H .
- From above, we can see that the response of a LTI system to a complex exponential is the same complex exponential multiplied by the complex factor $H(s)$.

Representations of Signals Using Eigenfunctions

- Consider a LTI system with input x , output y , and system function H .
- Suppose that the input x can be expressed as the linear combination of complex exponentials

$$x(t) = \sum_k a_k e^{s_k t},$$

where the a_k and s_k are complex constants.

- Using the fact that complex exponentials are eigenfunctions of LTI systems, we can conclude

$$y(t) = \sum_k a_k H(s_k) e^{s_k t}.$$

- Thus, if an input to a LTI system can be expressed as a linear combination of complex exponentials, the output can also be expressed as a linear combination of the *same* complex exponentials.
- The above formula can be used to determine the output of a LTI system from its input in a way that does not require convolution.